

Instructions – Hanging System Ryman Hanger

1. Screw the two Ryman plates (the steel bridge) in a vertical position to the rear of your artwork approximately a quarter of the way down the side frames. Place the screws in the centre of each slot (as this allows for adjustment later) and measure the distance from centre to centre of the two Ryman plates.
2. Fix two screws into the wall at the desired height and the same distance apart as the plates on the artwork. There should be approximately 1/8" clearance under the head of the screw.
3. Now hang the artwork so that the Ryman plates fit over the screw heads in the wall. Stand back and see if the artwork is hanging level. If required, remove it, loosen the Ryman Plate screws and adjust up or down to achieve the desired position before retightening.

If desired, you can add the Spring Keeper (or Security keeper) into the space between the artwork and the Ryman Plate, always with the spring facing towards the wall.